



**\*BEFORE USING PRODUCT: Refer to material safety data sheet**

1. Measure and pour 1 oz of solution into Model 510 and add tap water to "Fill Line"
2. Place restraints into unit and cover with lid
3. Set a timer for *ten (10) minutes minimum* to effectively disinfect restraints
4. After a full ten (10) minutes, remove restraints, rinse with tap water
5. Dry restraints completely
6. Lubricate locking mechanisms and hinges with Cuff Cleaner Lubricant